


Assembly Diagram



NO	PART NAME	QTY
1	BATTERY COVER	1
2	MEMBRANE STICKER	1
3	UPPER COVER	1
4	ELECTRODE PLATE	1
5	PLUS PLATE	1
6	MINUS PLATE	1
7	LED LAMP	1
8	MAIN PCB	1
9	CHECK VALVE CASE CAP	1
10	CHECK VALVE(2nd)	1
11	O-RING(CHECK VALVE CASE)	1
12	CHECK VALVE CASE	1
13	CHECK VALVE	1
14	O-RING(BODY)	1
15	BODY PACKING	1
16	BODY	1
17	O-RING(SPOUT)	1
18	SPOUT	1
19	JOINT NUT	1
20	SHOWER HEAD	1
21	SHOWER FACE	1
22	VALVE	1
23	CLIP HOLDER	1
24	SUCTION TUBE RING	2
25	SUCTION TUBE	1
26	MOTOR WIRE(2P)	1
27	SUCTION PIPE	1
28	WIRE PACKING	1
29	MOTOR CASE	1
30	MOTOR	1
31	MOTOR PACKING	1
32	MOTOR CASE COVER	1
33	IMPELLER	1
34	HOUSING	1
35	BODY JOINT NUT	1
36	BODY JOINT NUT PACKING	1
37	ADAPTER-A	1
38	ADAPTER-B	1
39	ADAPTER-WILLOW	1


• Specifications are subject to change without notice.

EASY WATER

INSTRUCTIONS AND PRECAUTIONS

※ Read all instructions and precautions before use.

MODEL: EF-13-WM



www.easyflo.com.au

Precautions for Use

These instructions are to ensure the product is used correctly, safely, and to prevent any possible risk or damage to the user and/or others people. Our company shall not take any responsibility for any failure of product, malfunction and damages caused by improper use by the user or third parties.

DANGER

If the directions of this sign are not followed, fatal accidents can happen and the user may die or get seriously injured.

WARNING

If the directions of this sign are not followed, accidents can happen or the user can get injured.

CAUTION

If the directions of this sign are not followed, the product can get damaged or the user can get injured.

DANGER

Only use for watering.

Do not use this pump for transferring the following liquids: Gasoline, Diesel, Water soluble fertilizers, Flammable liquids, Detergents, Kerosene, Acetone, Benzene, Cresol, Ethyl, Phenol, Methyl ethyl, Concentrated caustic soda liquid, Nitric acid, Hydrochloric acid, Sulfuric acid, thinner or solvents, Etc.

WARNING

Do not allow children to operate the product without adult supervision.

When disposing of pump, make sure to have it completely destroyed so that others won't use it again.

When you hand it over to another person, be sure to give them the instructions too.

CAUTION

After using the pump, do not keep it on its side or upside down.

Do not alter or disassemble the pump.

Do not run the pump 'dry' or let the pump idle without transferring.

Make sure to turn off the power after using the pump.

Do not shock the pump.

Use clean water only. Dirty water may cause mal function and/or pump failure.

Do not use this pump for hot liquids above 40°C (104°F).

Do not place the pump in a wet area.

When cleaning up the pump, do not use thinner, benzene, organic solvent, or glass cleaners.

When transporting the watering can and pump, remove pump from the watering can and close the cap on the watering can.

- ※ Replace all 4 batteries at the same time.
- ※ Use the same brand/type of batteries.
- ※ Make sure to take the batteries out before storing the pump.

EMERGENCY CASES WHEN ALL (4) BATTERIES ARE NOT AVAILABLE


It is recommended to use all 4 AA batteries but it is possible to operate with 2 AA batteries during emergencies.



WHEN TO REPLACE THE BATTERIES

Motor does not operate, even after pressing ON button or transfer rate becomes slower than in normal operation. Batteries can begin to discharge if they are stored for a long period of time. Check the expiration dates of batteries.


Names of Parts



Specifications

Delivery volume	Approx. 6 LPM (1.6 GPM)	Operating temperature	+5°C ~ 40°C (41°F ~ 104°F)
Suction tube length	Approx. 400mm (16")	Operating voltage	DC 3V
Spout length	Approx. 215mm (8.5")	Power source	AA battery x 4

Directions for Use



How to use the hose

